


LISBON COLLECTION


TOWEL RING 277464








Loosen the set screw on the accessory and remove the backing plate. Position the accessory against the wall and mark outline with pencil.





Predrill 3/16" holes on the wall to fit wall plugs. Insert wall plugs into the wall. Position backing plate flat side down over the plugs and install screws.

