


ASSEMBLY INSTRUCTIONS



Kinsley Medium Floor Lamp

Item # KS 1220

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Scissors

1. Carefully remove all parts from the box. Place on a clean, soft surface
2. Attach rubber washer (E) to nipple (D), then install stem (B) to base (F) and secure with metal washer (G), lock washer (H) and hex nut (I). Tighten using provided wrench.
3. To install shade (C) loosen check ring (K), then insert opening on shade spider (C) to fixture and secure with check ring (K). See diagram 1.
4. To adjust fixture height, loosen knob (A) and adjust to desired height, then tighten knob (A).
5. Install light bulb into the socket.
6. Remove protective cover (J) from plug.
7. Plug into electrical outlet and test fixture.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.