

- 1 Determine what type of wall you have: drywall, plaster, or masonry.
- 2 Purchase screws and anchors appropriate to your wall type and mirror weight. The Asana mirror weighs approximately 21 pounds. The head of the screw must be smaller than 5/16" in order to fit into the mounting holes on the back of the mirror.
- 3 There are three large mounting holes in the back of the frame of the Asana mirror. Select the two holes you wish to use based on the preferred orientation of the mirror on the wall.
- 4 Place your mirror on the wall where you want it to hang and mark the top center of the frame. Set the mirror aside.
- 5 Measure down from your center mark 2.5". Then from this mark, using a level, measure 5.5" to both sides\* and mark for your hanging hardware.

**\*IMPORTANT – Our products are handmade and there may be a variance. Please confirm the distance between the mounting holes is 11" before installing your hanging hardware.**

- 6 Double check your marks against the mirror mounting holes.
- 7 Install the anchors on the wall according to the anchor instructions and install screws in the wall anchors with the screw head out from the wall not more than 3/4". Hang your mirror by lining up the mounting holes and sliding the screws into the mounting holes.

